

## Optional Monitor Bases

Technical Specifications	
<b>Panavise Suction Cup Base</b> Part #: DMEZI-PVSM	
<b>Mounting Orientation</b>	<b>Vertical or Horizontal</b>
<b>Mounting Surfaces</b>	<b>Glass or other non porous surface</b>
<b>Movement Properties</b>	<b>Double Articulation</b>
<b>Type of Mount</b>	<b>Temporary-Semi Permanent</b>
<b>Weight</b>	<b>10oz (283g)</b>
<b>Warranty</b>	<b>1 Year</b>



1. Square Slide Nut – Fits into back of monitor
2. Adjustment knob for top articulation
3. Suction Push button – press button before flipping lever (4) to obtain maximum holding power.
4. Suction Activation Lever – when lever is in “up” position, press “push” button (3) and flip lever down.
5. Suction cup
6. Adjustment knob for lower articulation
7. Lower articulation joint
8. Top articulation joint, ball joint mounted allows full swivel movement.

Technical Specifications	
<b>Panavise Pedestal Monitor Base</b> Part #: DMEZI-PVPM	
<b>Mounting Orientation</b>	<b>Vertical or Horizontal</b>
<b>Mounting Surfaces</b>	<b>Any hard surface which base could be attached with screws</b>
<b>Movement Properties</b>	<b>Double Articulation</b>
<b>Type of Mount</b>	<b>Temporary to Permanent</b>
<b>Materials</b>	<b>Vinyl &amp; Metal</b>
<b>Weight</b>	<b>10oz (283g)</b>
<b>Warranty</b>	<b>1 Year</b>

1. Square Slide Nut – Fits into back of monitor
2. Tightening Nut
3. Adjustment knob for top articulation
4. Lower articulation adjustment knob
5. Mounting plate, screw down



Other Accessories

Technical Specifications	
<b>Ezi-Com Audio Adaptor</b> Part #: DMEZI-RHA	
Mounting Orientation	Vertical or Horizontal
Microphone	High gain auto level adjustment. Built in preamp.
Power Consumption	1200mWa (Ezi-Watch) monitor power supply)
Weight	1.6oz (45g)



- Ezi-Com audio Adaptor connects inline between Ezi-Com and Camera.
- High gain micro audio microphone
- Build in preamp

All Ezi-Com can transmit Audio, but only the audio enabled AV input for monitor can accept audio.

Standard Ezi-Com cables are not audio enabled. Audio enabled cables are available by custom order.

Panavise Suction Mount w/ AMPS Plate	
Part #: DMEZI-PVSM-AMPS	
Mounting Orientation	Vertical or Horizontal
Mounting Surfaces	Glass or other non porous surface
Movement Properties	Double Articulation
Type of Mount	Temporary-Semi Permanent
Weight	10oz (283g)



1. Thumb Lever to release Adhesive Foot
2. Adjustment knob for top articulation
3. Suction Push button – press button before flipping lever (4) to obtain maximum holding power.
4. Suction Activation Lever – when lever is in “up” position, press “push” button (3) and flip lever down.
5. Suction cup
6. Adjustment knob for lower articulation
7. Lower articulation joint
8. Seat for adhesive foot (Foot included in kit, but not pictured above)

Note: Adhesive Duck Foot not pictured above.

Suction Mount w/ AMPS plate and Adhesive Duck foot is a superior tool for the mounting of the Quad or DVR in a mobile unit.

Panavise Telescopic Camera Base	
Part #: DMEZI-PVT-1/420	
Mounting Orientation	Vertical or Horizontal
Mounting Surfaces	Any hard surface which base could be attached with screws
Movement Properties	Single Articulation, 6-11” adjustable telescopic rise
Type of Mount	Permanent
Materials	Vinyl & Metal
Weight	10oz (283g)
Length	Retracted: 8.5” Fully Extended: 13.5”



1. ¼-20 head for attachment into bottom of camera body (this head can be interchanged with the T-nut head on the suction monitor mount for mounting monitors)
2. Tightening Nut
3. Articulation Adjustment wing nut.
4. Telescopic rise adjustment. Twist to loosen and tighten.
5. Mounting base. Requires permanent mounting methods.

Telescopic Rise camera mount offers the added versatility to mounting a camera in areas that have a difficult viewing angle.